



Innovation & Quality

www.votatec.ca

## 3" Trimless Recessed Downlight

### Installation Steps:

Pre-Installation: Set Color Temperature

## Installation Instruction

### Cautions:

1. Do not use an electric generator to test the LED lamp.
2. Please abide by related country, regional and local laws and regulations when installing this fixture.
3. Please turn off the power at the circuit breaker before installation or maintenance.
4. Proper earth grounding is required to ensure safety.

### Notice:

1. To avoid the possibility of electrical shock or fire, the installation must be performed by a qualified electrician.
2. Please wear gloves to avoid injury during installation.
3. If any smoke or spark from the wire occurs, please turn off the power immediately and notify relevant personnel.

### Special functions instruction:

#### Color Temperature (CCT) Selectable

- Slide the switch to the corresponding position to select your desired color temperature:
- 2700K(Warm White)
- 3000K(Soft White)
- 3500K(Neutral White)
- 4000K(Cool White)
- 5000K(Daylight)

### Attention:

1. Please check the product for any damage after unpacking.
2. Please confirm all accessories (mud-in frame, screws, etc.) are complete before installation.

Locate the 5CCT selector switch on the driver or lamp body. Select your desired color temperature (2700K-5000K) using a small tool before proceeding with mounting.


### Wiring Diagram

- Fixture Black (L) Wire

**Step 1. Cut Ceiling Hole:**


Cut a Ø 3-3/8 inch (86mm) hole in the ceiling at the desired location. (Refer to Figure 1).

1

**Step 3. Apply Plaster:**


Apply plaster or joint compound over the mud-in frame and smooth it flush with the surrounding ceiling. The frame should be completely concealed, creating a seamless finish. Allow the plaster to dry completely. (Refer to Figure 3).

3

**Step 2. Fix Mud-in Frame:**


Secure the mud-in frame to the ceiling using the provided 4 screws. Ensure it is level and firmly attached. (Refer to Figure 2).

2

**Step 4. Connect Wires:**

Ensure power is OFF. Pass the driver and its wires through the hole. Connect the driver's wires to the household supply wires using the quick-connect push-in terminals: (Refer to Figure 4).

4

**Step 5. Place Driver & Connect Lamp:**


Gently push the driver into the ceiling cavity. Then, connect the lamp body to the driver via the quick-connect terminal. (Refer to Figure 5).

5

**Step 6. Install Lamp Body:**

Ensure the snap buckles are opened. Align the lamp body with the mud-in frame and press firmly. The internal "Push & Lock" mechanism will engage and hold the fixture securely in place, flush with the ceiling. (Refer to Figure 6).

6



Ensure the snap buckles are opened.

**Step 7. Finished Installation:**

The installed downlight should sit perfectly flush with the ceiling, providing a seamless and modern aesthetic. (Refer to Figure 7).

7

**Warning/ Avertissement**

SUPPLY CONDUCTORS MUST BE RATED FOR AT LEAST 75°C.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A QUALIFIED PERSON FAMILIAR WITH ITS CONSTRUCTION, OPERATION, AND ASSOCIATED HAZARDS.

LES CONDUCTEURS D'ALIMENTATION DOIVENT AVOIR UN INDICE DE TEMPÉRATURE D'AU MOINS 75 °C.

CE PRODUIT DOIT ÊTRE INSTALLÉ CONFORMÉMENT AUX NORMES D'INSTALLATION APPLICABLES PAR UN TECHNICIEN QUALIFIÉ, CONNAISSANT SA CONSTRUCTION, SON FONCTIONNEMENT ET LES RISQUES ASSOCIÉS.